


## W900-W901



MOST CLIENTS BELIEVE THEIR CODE STARTS WITH AN 1, BUT ACTUALLY YOU HAVE TO REMOVE THE 1 FROM THE FRONT OF THEIR KEYPAD CODE TO DO THE OTHER PROGRAM FEATURES.

EXAMPLE:	KEYPAD CODE	12345
	ACTUAL KEYPAD CODE	2345

### FEATURES FROM ANY KEYPAD

<i>ARM, DISARM, OR RESET:</i>	<b>1 + CODE</b>
<b>FIRE RESET:</b>	<b>1 + CODE + 1 + CODE</b>
<i>MAID'S KEYPAD CODE:</i>	<b>4 + CODE (TRIANGLE LIGHT MUST BE ON MASTER KEYPAD)</b>
<b>DURESS:</b>	<b>5 + CODE</b>
<i>PRIMARY INTERIOR SENSORS ON/OFF:</i>	<b>3 + CODE</b>
<b>SECONDARY INTERIOR SENSORS ON/OFF:</b>	<b>2 + CODE</b>
<i>FORCEARM:</i>	<b>6 + CODE</b>

**FEATURES FROM MASTER KEYPAD**

**CHANGE MAID'S KEYPAD CODE:** 4 + TRIANGLE + MASTER CODE + NEW MAID'S CODE + TRIANGLE

**MAID'S CODE ON/OFF:** TRIANGLE


**CHIME ON/OFF:** SQUARE + SQUARE

**NITE ON/OFF:** SQUARE + 3

**ALARM MEMORY:** WESTEC LOGO + WESTEC LOGO


**TROUBLE SILENCE:** TRB SILENCE + TRB SILENCE


**TEST:** TEST + TEST (BURGLARY MUST BE DISARMED)



**MAIN PANEL**

**DOOR CLOSED**





DOOR OPEN

**ON/OFF SWITCH:**

TWO BLACK SWITCHES LOCATED IN THE CENTER LEFT SIDE. SWITCH IS ON TOP AND IT STICKS OUT FARTHER THAN THE SWITCH ON BOTTOM. DO NOT USE THE SWITCH ON THE BOTTOM, YOU MAY ERASE THE SYSTEM'S CODE

**PROGRAM SWITCH:** TWO BLACK SWITCHES LOCATED IN THE CENTER LEFT SIDE. SWITCH IS ON BOTTOM AND DOESN'T STICK OUT AS FAR AS THE TOP SWITCH. THE SERVICE TECHNICIANS USE THIS SWITCH TO PROGRAM THE SYSTEM

**TEST:** DON'T USE TEST BUTTON ON MAIN PANEL-MAY SHORT SYSTEM OUT-ADVISE CUSTOMER TO USE THE TEST BUTTON ON KEYPAD

**TROUBLE SILENCE:** DON'T USE THE TROUBLE SILENCE BUTTON ON MAIN PANEL-MAY SHORT SYSTEM OUT-ADVISE CUSTOMER TO USE THE TROUBLE SILENCE BUTTON ON KEYPAD